

"Relied on Worldwide in the Most Extreme Conditions"

## Bird-B-Gone Strip BB-525 24" Strip



## Installation

- 1. Wrap the Bird-B-Gone Strip around the collector funnel of the rain gauge.
- 2. Attach the ends of the strip together with the enclosed cable ties.
- 3. You may also use a small amount of silicone adhesive to lock in place.
- 4. Bend the spikes upward for full coverage.