



"Relied on Worldwide in the Most Extreme Conditions"



Bird-B-Gone Strip User's Manual

Installation

Instructions for installing Bird-B-Gone Strip on Rain Gauge

1. Wrap the Bird-B-Gone Strip around the collector funnel of the rain gauge.
2. Attach the ends of the strip together with the enclosed cable ties.
3. You may also use a small amount of silicone adhesive to lock in place.
4. Bend the spikes upward for full coverage.

