

## Rain Gauge Tipping Bucket

### TR-525-W2-S Series Rainfall Sensor



#### Description

The Texas Electronics, Inc. TR-525-W2-S Rainfall Sensor with a WMO standard 200mm diameter funnel is a remote tipping bucket style rain gauge that measures liquid precipitation. It utilizes a unique siphoning mechanism that allows an extended range of accuracy. This system allows control of the "flow rate" of accumulated precipitation. This metering geometry assures higher levels in both accuracy and repeatability during periods of extremely heavy rainfall. The Rain Gauge is a freestanding receptacle for measuring precipitation.. The TR-525-W2-S was specifically designed to meet the National Weather Service & World Meteorological Organization requirements for rainfall measurement.

#### Features & Benefits

- Unique siphoning technique allows for wide accuracy
- Meets WMO requirements for a 200mm collector
- Interfaces with virtually all data acquisition systems
- Knife-edge collector optimizes rainfall catch
- Exceptional splash-out protection improves accuracy in high winds
- Easy installation and maintenance
- Over 30 years in production
- Aluminum (anodized and powder coated) exterior for weather resistance
- Integrated bubble level

#### Specifications

Resolution:	0.1mm, 0.2mm, 0.5mm 1.0mm (additional fee), 0.01"
Accuracy:	0-10 in. (254 mm) per hour; +/-2% 10-20 in. (508 mm) per hour; +/-3%
Siphon starting threshold:	<0.01" (<0.254 mm)
Range:	700 mm per hour (27")
Collector diameter:	200 mm with knife-edge
Funnel depth:	163 mm (6.4")
Splash out protection:	50 mm (2")
Operating Temp:	32 to 140° F (0 to 60° C)
Storage Temp:	-40 to 185° F (-40 to 70° C)
Humidity Limits:	0 to 100%
Weight:	1.8 lbs
Height:	11.125"
Cable:	10', 24 gauge 2 conductor
Switch:	Momentary potted reed switch
Switch rating:	30 VDC @ 2 A, 115 VAC @ 1 A
Switch Closure Time:	135 ms
Bounce Settling Time:	0.75 ms
Pivot:	Ground bronze pivots with hardened stainless steel shaft
Bucket:	Black PP injection molded
Level:	Integral Bubble Level
Warranty:	3 years

#### Installation & Maintenance

Installation consists of attaching the three sensor support legs to a firm platform (such as our MB-525 Mounting Base). Pole mounting on the mast of a weather station is available by securing to the included side bracket.

Maintenance consists of routine cleaning of debris from the filter screen, and occasional calibration verification with our FC-500 Field Calibration Kit.

#### Ordering Information

Model #: TR-525-W2-S

Description: Rain Gauge, 200mm collector  
(Please specify calibration)

#### Optional Parts / Accessories

Pendant Datalogger  
MB-525 Pole Mounting Base  
FC-500 Field Calibration Kit  
BB-525 Bird Repellant  
HT-525 Heater, 120 VAC